

HEAVY TRAFFIC

StoneyCrete™
PERVIOUS PAVEMENT

6"

Non-woven
geotextile
filter fabric
(See note 3)

1-1/2" - 2"
CLEAN AGGREGATE
(No Fines)

10" min.
(See Note 2)

SUBGRADE
(See Note 1)

NOTES:

1. Scarify organic material (3" min.), then roll to identify & eliminate any wet, soft or puddling areas.
2. Geo-tech engineering study must be completed to assure support & permeability of subsoil.
3. Use a non-woven polypropylene geotextile filter fabric. Fabric should be inert to biological degradation & chemical alkali & acid resistant. (like Miraki® 140NC)

TYPICAL DESIGN SECTION

SCALE: 3"=1'-0"



STONEY CREEK MATERIALS, L.L.C.

PH: (512) 261-0821 FX: (512) 261-8709
WWW.STONEYCREEKMATERIALS.COM

25 STONEY CREEK COVE
AUSTIN, TEXAS 78734

Date:
6/5/03

File:
Sht4.dwg

Sheet:
E4